



Suspension Parts & Poly Bushing for LAND ROVER

LAND ROVER 90/110

LAND ROVER DEFENDER

LAND ROVER DISCOVERY

LAND ROVER DISCOVERY SPORT

LAND ROVER FREELANDER

LAND ROVER FREELANDER 2

LAND ROVER RANGE ROVER

LAND ROVER RANGE ROVER EVOQUE

LAND ROVER RANGE ROVER SPORT

LAND ROVER Series 2, 2A, 3

SuperPro Suspension Parts & Poly Bushing Catalogue

More available at www.superpro.com.au



LAND ROVER 90/110 Chassis KA - 1983-1994

Position	Part Name	Part No.	Qty/Car	Sub Brand
Front	Panhard Rod Bush Kit	SPF0194K	1	SuperPro SPF
Front	Radius Arm To Diff Mount Bush Kit	SPF0126K	1	SuperPro SPF
Front	Radius Arm To Diff Mount Bush Kit Offset	SPF2559K	1	SuperPro SPF
Front	Radius Arm To Chassis Mount Bush Kit	SPF0206K	1	SuperPro SPF
Front	Radius Arm To Chassis Mount Performance Use	SPF3632K	1	SuperPro SPF
Front	Radius Arm To Chassis Setback Bush Kit	SPF2717K	1	SuperPro SPF
Front	Radius Arm To Chassis Setback Bush Kit	SPF2718K	1	SuperPro SPF
Front	Shock Absorber Upper & Lower Bush Kit	SPF0075K	2	SuperPro SPF
Front	Shock Absorber Upper & Lower Bush Kit	SPF1879K	2	SuperPro SPF
Front	Sway Bar Link Bush Kit	SPF0078K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit	SPF0666-23K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit	SPF0666-24K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit	SPF0666-25K	1	SuperPro SPF
Front and Rear	Enhancement Bush Kit	KIT040K	1	Vehicle Kits
Front and Rear	Radius Arms & Panhard Rods Bush Kit	KIT043BADJK	1	Vehicle Kits
Front and Rear	Radius Arms & Panhard Rods Bush Kit	KIT043BK	1	Vehicle Kits
Rear	Radius Arm To Diff Mount Bush Kit	SPF0129K	1	SuperPro SPF
Rear	Radius Arm To Chassis Mount Bush Kit	SPF0323K	1	SuperPro SPF
Rear	Shock Absorber Lower Bush Kit	SPF0075K	1	SuperPro SPF
Rear	Shock Absorber Lower Bush Kit	SPF1879K	1	SuperPro SPF
Rear	Shock Absorber Upper Bush Kit	SPF0779K	1	SuperPro SPF
Rear	Sway Bar Link Bush Kit	SPF0078K	1	SuperPro SPF
Rear	Sway Bar Mount Bush Kit	SPF0666-23K	1	SuperPro SPF
Rear	Sway Bar Mount Bush Kit	SPF0666-24K	1	SuperPro SPF
Rear	Sway Bar Mount Bush Kit	SPF2303-22K	1	SuperPro SPF
Rear	Trailing Arm Upper Bush Kit	SPF0128K	1	SuperPro SPF

LAND ROVER DEFENDER Chassis LA-on - 1993-2002

Position	Part Name	Part No.	Qty/Car	Sub Brand
Front	Panhard Rod Bush Kit	SPF0194K	1	SuperPro SPF
Front	Radius Arm To Diff Mount Bush Kit	SPF0195K	1	SuperPro SPF
Front	Radius Arm To Chassis Mount Bush Kit	SPF0206K	1	SuperPro SPF
Front	Radius Arm To Chassis Setback Bush Kit	SPF2717K	1	SuperPro SPF
Front	Radius Arm To Chassis Setback Bush Kit	SPF2718K	1	SuperPro SPF
Front	Radius Arm To Diff Mount Bush Kit - Caster Correction	SPF2509K	1	SuperPro SPF
Front	Shock Absorber Upper & Lower Bush Kit	SPF0075K	1	SuperPro SPF
Front	Shock Absorber Upper & Lower Bush Kit	SPF1879K	1	SuperPro SPF
Front	Sway Bar Link Bush Kit	SPF0078K	1	SuperPro SPF

SuperPro Suspension Parts & Poly Bushing Catalogue

More available at www.superpro.com.au



LAND ROVER DEFENDER Chassis LA-on - 1993-2002

Position	Part Name	Part No.	Qty/Car	Sub Brand
Front	Sway Bar Mount Bush Kit	SPF0666-25K	1	SuperPro SPF
Front and Rear	Radius Arms & Panhard Rod Bush Kit - Caster Correction	KIT043AADJK	1	Vehicle Kits
Front and Rear	Radius Arms & Panhard Rods Bush Kit	KIT043AK	1	Vehicle Kits
Rear	Radius Arm To Diff Mount Bush Kit	SPF0129K	1	SuperPro SPF
Rear	Radius Arm To Chassis Mount Bush Kit	SPF0323K	1	SuperPro SPF
Rear	Shock Absorber Lower Bush Kit	SPF0075K	1	SuperPro SPF
Rear	Shock Absorber Lower Bush Kit	SPF2656K	1	SuperPro SPF
Rear	Shock Absorber Upper Bush Kit	SPF0779K	1	SuperPro SPF
Rear	Sway Bar Link Bush Kit	SPF0078K	1	SuperPro SPF
Rear	Sway Bar Mount Bush Kit	SPF0666-19K	1	SuperPro SPF
Rear	Sway Bar Mount Bush Kit	SPF1697-18K	1	SuperPro SPF
Rear	Sway Bar Mount Bush Kit	SPF2303-19K	1	SuperPro SPF
Rear	Trailing Arm Upper Bush Kit	SPF0128K	1	SuperPro SPF

LAND ROVER DEFENDER Chassis YA-on, TD5 - 2002-2007

Position	Part Name	Part No.	Qty/Car	Sub Brand
Front	Panhard Rod Bush Kit	SPF1803K	1	SuperPro SPF
Front	Radius Arm To Diff Mount Bush Kit	SPF0195K	1	SuperPro SPF
Front	Radius Arm To Diff Mount Bush Kit	SPF0195SK	1	SuperPro SPF
Front	Radius Arm To Chassis Mount Bush Kit	SPF0206K	1	SuperPro SPF
Front	Radius Arm To Chassis Mount Performance Use	SPF3632K	1	SuperPro SPF
Front	Radius Arm To Chassis Setback Bush Kit	SPF2717K	1	SuperPro SPF
Front	Radius Arm To Chassis Setback Bush Kit	SPF2718K	1	SuperPro SPF
Front	Radius Arm To Diff Mount Bush Kit - Caster Correction	SPF2509K	1	SuperPro SPF
Front	Shock Absorber Upper & Lower Bush Kit	SPF0075K	2	SuperPro SPF
Front	Shock Absorber Upper & Lower Bush Kit	SPF1879K	2	SuperPro SPF
Front	Sway Bar Link Bush Kit	SPF0078K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit	SPF0666-23K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit	SPF0666-24K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit	SPF0666-25K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit	SPF0666-26K	1	SuperPro SPF
Front and Rear	Radius Arms & Panhard Rod Bush Kit - Caster Correction	KIT043CADJK	1	SuperPro SPF
Front and Rear	Radius Arms & Panhard Rods Bush Kit	KIT043CK	1	SuperPro SPF
Rear	Radius Arm To Diff Mount Bush Kit	SPF0129K	1	SuperPro SPF
Rear	Radius Arm To Chassis Mount Bush Kit	SPF0323K	1	SuperPro SPF
Rear	Shock Absorber Lower Bush Kit	SPF0075K	1	SuperPro SPF
Rear	Shock Absorber Lower Bush Kit	SPF1879K	1	SuperPro SPF

SuperPro Suspension Parts & Poly Bushing Catalogue

More available at www.superpro.com.au



LAND ROVER DEFENDER Chassis YA-on, TD5 - 2002-2007

Position	Part Name	Part No.	Qty/Car	Sub Brand
Rear	Shock Absorber Lower Bush Kit	SPF2656K	1	SuperPro SPF
Rear	Shock Absorber Upper Bush Kit	SPF0078K	1	SuperPro SPF
Rear	Shock Absorber Upper Bush Kit	SPF0779K	1	SuperPro SPF
Rear	Sway Bar Link Bush Kit	SPF0078K	1	SuperPro SPF
Rear	Sway Bar Mount Bush Kit	SPF0666-23K	1	SuperPro SPF
Rear	Sway Bar Mount Bush Kit	SPF0666-24K	1	SuperPro SPF
Rear	Sway Bar Mount Bush Kit	SPF1697-18K	1	SuperPro SPF
Rear	Sway Bar Mount Bush Kit	SPF2303-18K	1	SuperPro SPF
Rear	Sway Bar Mount Bush Kit	SPF2303-19K	1	SuperPro SPF
Rear	Sway Bar Mount Bush Kit	SPF2303-22K	1	SuperPro SPF
Rear	Trailing Arm Upper Bush Kit	SPF0128K	1	SuperPro SPF

LAND ROVER DEFENDER Puma Engined Cars - 2007-on

Position	Part Name	Part No.	Qty/Car	Sub Brand
Front	Panhard Rod Bush Kit	SPF1803K	1	SuperPro SPF
Front	Radius Arm To Diff Mount Bush Kit	SPF0195K	1	SuperPro SPF
Front	Radius Arm To Diff Mount Bush Kit	SPF0195SK	1	SuperPro SPF
Front	Radius Arm To Chassis Mount Bush Kit	SPF0206K	1	SuperPro SPF
Front	Radius Arm To Chassis Mount Performance Use	SPF3632K	1	SuperPro SPF
Front	Radius Arm To Chassis Setback Bush Kit	SPF2717K	1	SuperPro SPF
Front	Radius Arm To Chassis Setback Bush Kit	SPF2718K	1	SuperPro SPF
Front	Radius Arm To Diff Mount Bush Kit - Caster Correction	SPF2509K	1	SuperPro SPF
Front	Shock Absorber Upper & Lower Bush Kit	SPF0075K	2	SuperPro SPF
Front	Shock Absorber Upper & Lower Bush Kit	SPF1879K	2	SuperPro SPF
Front	Sway Bar Link Bush Kit	SPF0078K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit	SPF0666-26K	1	SuperPro SPF
Rear	Radius Arm To Diff Mount Bush Kit	SPF0129K	1	SuperPro SPF
Rear	Radius Arm To Chassis Mount Bush Kit	SPF0323K	1	SuperPro SPF
Rear	Shock Absorber Lower Bush Kit	SPF0075K	1	SuperPro SPF
Rear	Shock Absorber Lower Bush Kit	SPF1879K	1	SuperPro SPF
Rear	Shock Absorber Lower Bush Kit	SPF2656K	1	SuperPro SPF
Rear	Shock Absorber Upper Bush Kit	SPF0078K	1	SuperPro SPF
Rear	Shock Absorber Upper Bush Kit	SPF0779K	1	SuperPro SPF
Rear	Sway Bar Link Bush Kit	SPF0078K	1	SuperPro SPF
Rear	Sway Bar Mount Bush Kit	SPF2303-18K	1	SuperPro SPF
Rear	Trailing Arm Upper Bush Kit	SPF0128AK	1	SuperPro SPF

SuperPro Suspension Parts & Poly Bushing Catalogue

More available at www.superpro.com.au



LAND ROVER DISCOVERY Series 1 - 1989-1998

Position	Part Name	Part No.	Qty/Car	Sub Brand
Front	Panhard Rod Bush Kit	SPF0194K	1	SuperPro SPF
Front	Radius Arm To Diff Mount Bush Kit	SPF0195K	1	SuperPro SPF
Front	Radius Arm To Diff Mount Bush Kit	SPF0195SK	1	SuperPro SPF
Front	Radius Arm To Chassis Mount Bush Kit	SPF0206K	1	SuperPro SPF
Front	Radius Arm To Chassis Mount Performance Use	SPF3632K	1	SuperPro SPF
Front	Radius Arm To Chassis Setback Bush Kit	SPF2717K	1	SuperPro SPF
Front	Radius Arm To Chassis Setback Bush Kit	SPF2718K	1	SuperPro SPF
Front	Radius Arm To Diff Mount Bush Kit - Caster Correction	SPF2509K	1	SuperPro SPF
Front	Shock Absorber Upper & Lower Bush Kit	SPF0075K	2	SuperPro SPF
Front	Shock Absorber Upper & Lower Bush Kit	SPF1879K	2	SuperPro SPF
Front	Sway Bar Mount Bush Kit	SPF0666-18K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit	SPF0666-19K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit	SPF0666-20K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit	SPF0666-22K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit	SPF0666-23K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit	SPF0666-24K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit	SPF0666-25K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit	SPF0666-26K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit	SPF0666-27K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit	SPF0666-28K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit	SPF0666-30K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit	SPF0666-33K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit	SPF0666-38K	1	SuperPro SPF
Front and Rear	Radius Arms & Panhard Rods Bush Kit	KIT043AADJK	1	Vehicle Kits
Front and Rear	Radius Arms & Panhard Rods Bush Kit	KIT043AK	1	Vehicle Kits
Rear	Radius Arm To Diff Mount Bush Kit	SPF0129K	1	SuperPro SPF
Rear	Radius Arm To Chassis Mount Bush Kit	SPF0323K	1	SuperPro SPF
Rear	Shock Absorber Lower Bush Kit	SPF0075K	1	SuperPro SPF
Rear	Shock Absorber Lower Bush Kit	SPF1879K	1	SuperPro SPF
Rear	Shock Absorber Lower Bush Kit	SPF2656K	1	SuperPro SPF
Rear	Shock Absorber Upper Bush Kit	SPF0779K	1	SuperPro SPF
Rear	Sway Bar Mount Bush Kit	SPF0666-18K	1	SuperPro SPF
Rear	Sway Bar Mount Bush Kit	SPF0666-19K	1	SuperPro SPF
Rear	Sway Bar Mount Bush Kit	SPF0666-20K	1	SuperPro SPF
Rear	Sway Bar Mount Bush Kit	SPF0666-22K	1	SuperPro SPF
Rear	Sway Bar Mount Bush Kit	SPF0666-23K	1	SuperPro SPF
Rear	Sway Bar Mount Bush Kit	SPF0666-24K	1	SuperPro SPF
Rear	Sway Bar Mount Bush Kit	SPF0666-25K	1	SuperPro SPF
Rear	Sway Bar Mount Bush Kit	SPF0666-26K	1	SuperPro SPF
Rear	Sway Bar Mount Bush Kit	SPF0666-27K	1	SuperPro SPF

SuperPro Suspension Parts & Poly Bushing Catalogue

More available at www.superpro.com.au



LAND ROVER DISCOVERY Series 1 - 1989-1998

Position	Part Name	Part No.	Qty/Car	Sub Brand
Rear	Sway Bar Mount Bush Kit	SPF0666-28K	1	SuperPro SPF
Rear	Sway Bar Mount Bush Kit	SPF0666-30K	1	SuperPro SPF
Rear	Sway Bar Mount Bush Kit	SPF0666-33K	1	SuperPro SPF
Rear	Sway Bar Mount Bush Kit	SPF0666-38K	1	SuperPro SPF
Rear	Trailing Arm Upper Bush Kit	SPF0128K	1	SuperPro SPF

LAND ROVER DISCOVERY Series 2 - 1998-2004

Position	Part Name	Part No.	Qty/Car	Sub Brand
Front	Panhard Rod Bush Kit	SPF1803K	1	SuperPro SPF
Front	Radius Arm To Diff Mount Bush Kit	SPF2134K	1	SuperPro SPF
Front	Radius Arm To Diff Mount Bush Kit Offset	SPF2560K	1	SuperPro SPF
Front	Radius Arm To Diff Mount Bush Kit Offset	SPF2560XK	1	SuperPro SPF
Front	Radius Arm To Chassis Mount Bush Kit	SPF2128-80K	1	SuperPro SPF
Front	Radius Arm To Chassis Mount Bush Kit	SPF2128K	1	SuperPro SPF
Front	Sway Bar Link Bush Kit	SPF0078K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit	SPF2136-19K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit	SPF2136-30K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit	SPF2136-35K	1	SuperPro SPF
Rear	Radius Arm To Diff Mount Bush Kit	SPF2135K	1	SuperPro SPF
Rear	Radius Arm To Chassis Mount Bush Kit	SPF2128-80K	1	SuperPro SPF
Rear	Radius Arm To Chassis Mount Bush Kit	SPF2128K	1	SuperPro SPF
Rear	Sway Bar Mount Bush Kit	SPF2136-19K	1	SuperPro SPF
Rear	Sway Bar Mount Bush Kit	SPF2136-30K	1	SuperPro SPF
Rear	Sway Bar Mount Bush Kit	SPF2136-35K	1	SuperPro SPF
Rear	Watts Link Bush Kit	SPF4400K	1	Roll Control

LAND ROVER DISCOVERY Series 3 - 2004-2009

Position	Part Name	Part No.	Qty/Car	Sub Brand
Front	Control Arm Lower-Inner Front Bush Kit	SPF3459K	1	SuperPro SPF
Front	Control Arm Lower-Inner Rear Bush Kit	SPF3456K	1	SuperPro SPF
Front	Control Arm Upper-Inner Bush Kit	SPF3486K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit	SPF3701-28K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit	SPF3701-31K	1	Roll Control
Front	Sway Bar Mount Bush Kit	SPF3701-34K	1	SuperPro SPF
Rear	Control Arm Lower-Front Bush Kit	SPF3627K	1	SuperPro SPF
Rear	Control Arm Lower-Rear Bush Kit	SPF3628K	1	SuperPro SPF
Rear	Control Arm Upper-Front Bush Kit	SPF3630K	1	SuperPro SPF
Rear	Sway Bar Link Kit - Heavy Duty Adjustable	TRC1245	1	Roll Control

SuperPro Suspension Parts & Poly Bushing Catalogue

More available at www.superpro.com.au



LAND ROVER DISCOVERY Series 3 - 2004-2009

Position	Part Name	Part No.	Qty/Car	Sub Brand
Rear	Sway Bar Mount Bush Kit	SPF3631-22K	1	SuperPro SPF
Rear	Sway Bar Mount Bush Kit	SPF3631-23K	1	Roll Control
Rear	Sway Bar Mount Bush Kit	SPF3631-34K	1	SuperPro SPF

LAND ROVER DISCOVERY Series 4 - 2009-on

Position	Part Name	Part No.	Qty/Car	Sub Brand
Front	Control Arm Lower-Inner Front Bush Kit	SPF3459K	1	SuperPro SPF
Front	Control Arm Lower-Inner Rear Bush Kit	SPF3456K	1	SuperPro SPF
Front	Control Arm Upper-Inner Bush Kit	SPF3486K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit	SPF3701-28K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit	SPF3701-31K	1	Roll Control
Front	Sway Bar Mount Bush Kit	SPF3701-34K	1	SuperPro SPF
Rear	Control Arm Lower-Front Bush Kit	SPF3627K	1	SuperPro SPF
Rear	Control Arm Lower-Rear Bush Kit	SPF3628K	1	SuperPro SPF
Rear	Control Arm Upper-Front Bush Kit	SPF3630K	1	SuperPro SPF
Rear	Sway Bar Link Kit - Heavy Duty Adjustable	TRC1245	1	Roll Control
Rear	Sway Bar Mount Bush Kit	SPF3631-22K	1	SuperPro SPF
Rear	Sway Bar Mount Bush Kit	SPF3631-23K	1	Roll Control
Rear	Sway Bar Mount Bush Kit	SPF3631-34K	1	SuperPro SPF

LAND ROVER DISCOVERY SPORT LC - 2014-on

Position	Part Name	Part No.	Qty/Car	Sub Brand
Front	Sway Bar Link Kit - Heavy Duty Adjustable	TRC10245	1	Roll Control

LAND ROVER FREELANDER LN - 02/1998-10/2006

Position	Part Name	Part No.	Qty/Car	Sub Brand
Front	Camber Adjusting Bolt Kit	SPF4351-14K	1	SuperPro SPF
Front	Camber Adjusting Bolt Kit	SPF4351-17K	1	SuperPro SPF
Front	Control Arm Lower-Inner Front Bush Kit	SPF1759K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit	SPF1763-20K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit	SPF1763-21K	1	SuperPro SPF
Rear	Control Arm Bush Kit	SPF1762K	1	SuperPro SPF
Rear	Control Arm Front Bush Kit	SPF1761K	1	SuperPro SPF
Rear	Control Arm Rear Bush Kit	SPF1761K	2	SuperPro SPF
Rear	Trailing Arm Front Bush Kit	SPF1760K	1	SuperPro SPF

SuperPro Suspension Parts & Poly Bushing Catalogue

More available at www.superpro.com.au



LAND ROVER FREELANDER 2 FA_ - 2006-2014

Position	Part Name	Part No.	Qty/Car	Sub Brand
Front	Sway Bar Link Kit - Heavy Duty Adjustable	TRC10160	1	Roll Control
Rear	Sway Bar Link Kit - Heavy Duty Adjustable	TRC10160	1	Roll Control

LAND ROVER RANGE ROVER Classic (Air Suspension) - 1992-1995

Position	Part Name	Part No.	Qty/Car	Sub Brand
Front	Panhard Rod Bush Kit	SPF0194K	1	SuperPro SPF
Front	Panhard Rod Bush Kit	SPF1803K	1	SuperPro SPF
Front	Radius Arm To Diff Mount Bush Kit	SPF0195K	1	SuperPro SPF
Front	Radius Arm To Diff Mount Bush Kit	SPF0195SK	1	SuperPro SPF
Front	Radius Arm To Diff Mount Bush Kit	SPF1809K	1	SuperPro SPF
Front	Radius Arm To Chassis Mount Bush Kit	SPF0206K	1	SuperPro SPF
Front	Radius Arm To Chassis Mount Performance Use	SPF3632K	1	SuperPro SPF
Front	Radius Arm To Chassis Setback Bush Kit	SPF2717K	1	SuperPro SPF
Front	Radius Arm To Chassis Setback Bush Kit	SPF2718K	1	SuperPro SPF
Front	Radius Arm To Diff Mount Bush Kit - Caster Correction	SPF2509K	1	SuperPro SPF
Front	Shock Absorber Lower Bush Kit	SPF0740K	1	SuperPro SPF
Front	Shock Absorber Upper & Lower Bush Kit	SPF0075K	2	SuperPro SPF
Front	Shock Absorber Upper & Lower Bush Kit	SPF1879K	2	SuperPro SPF
Front	Sway Bar Link Bush Kit	SPF0078K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit	SPF0666-26K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit	SPF0666-27K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit	SPF0666-28K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit	SPF1802-31K	1	SuperPro SPF
Front and Rear	Radius Arms & Panhard Rods Bush Kit	KIT043AADJK	1	Vehicle Kits
Front and Rear	Radius Arms & Panhard Rods Bush Kit	KIT043AK	1	Vehicle Kits
Front and Rear	Radius Arms & Panhard Rods Bush Kit	KIT090K	1	Vehicle Kits
Rear	Panhard Rod Bush Kit	SPF1803K	1	SuperPro SPF
Rear	Radius Arm To Diff Mount Bush Kit	SPF0129K	1	SuperPro SPF
Rear	Radius Arm To Chassis Mount Bush Kit	SPF0323K	1	SuperPro SPF
Rear	Radius Arm To Chassis Mount Bush Kit	SPF1805K	1	SuperPro SPF
Rear	Shock Absorber Lower Bush Kit	SPF0075K	1	SuperPro SPF
Rear	Shock Absorber Lower Bush Kit	SPF0740K	1	SuperPro SPF
Rear	Shock Absorber Lower Bush Kit	SPF1879K	1	SuperPro SPF
Rear	Shock Absorber Lower Bush Kit	SPF2656K	1	SuperPro SPF
Rear	Shock Absorber Upper Bush Kit	SPF0078K	1	SuperPro SPF
Rear	Shock Absorber Upper Bush Kit	SPF0779K	1	SuperPro SPF
Rear	Sway Bar Link Bush Kit	SPF0078K	1	SuperPro SPF
Rear	Sway Bar Mount Bush Kit	SPF0666-26K	1	SuperPro SPF

SuperPro Suspension Parts & Poly Bushing Catalogue

More available at www.superpro.com.au



LAND ROVER RANGE ROVER Classic (Air Suspension) - 1992-1995

Position	Part Name	Part No.	Qty/Car	Sub Brand
Rear	Sway Bar Mount Bush Kit	SPF0666-27K	1	SuperPro SPF
Rear	Sway Bar Mount Bush Kit	SPF0666-28K	1	SuperPro SPF
Rear	Trailing Arm Upper Bush Kit	SPF0128K	1	SuperPro SPF

LAND ROVER RANGE ROVER Classic - 1969-1986

Position	Part Name	Part No.	Qty/Car	Sub Brand
Front	Panhard Rod Bush Kit	SPF2156K	1	SuperPro SPF
Front	Radius Arm To Diff Mount Bush Kit	SPF0126K	1	SuperPro SPF
Front	Radius Arm To Diff Mount Bush Kit Offset	SPF2559K	1	SuperPro SPF
Front	Radius Arm To Chassis Mount Bush Kit	SPF0127K	1	SuperPro SPF
Front	Shock Absorber Upper & Lower Bush Kit	SPF0075K	2	SuperPro SPF
Front and Rear	Body Mount Bush Kit	SPF1788K	10	SuperPro SPF
Front and Rear	Radius Arms & Panhard Rods Bush Kit	KIT042ADJK	1	Vehicle Kits
Front and Rear	Radius Arms & Panhard Rods Bush Kit	KIT042K	1	Vehicle Kits
Rear	Radius Arm To Diff Mount Bush Kit	SPF0129K	1	SuperPro SPF
Rear	Radius Arm To Chassis Mount Bush Kit	SPF0130K	1	SuperPro SPF
Rear	Shock Absorber Lower Bush Kit	SPF0075K	1	SuperPro SPF
Rear	Shock Absorber Upper Bush Kit	SPF0078K	1	SuperPro SPF
Rear	Shock Absorber Upper Bush Kit	SPF0078K	1	SuperPro SPF
Rear	Trailing Arm Upper Bush Kit	SPF0128K	1	SuperPro SPF

LAND ROVER RANGE ROVER Classic - 1987-1992

Position	Part Name	Part No.	Qty/Car	Sub Brand
Front	Radius Arm To Diff Mount Bush Kit	SPF0195K	1	SuperPro SPF
Front	Radius Arm To Chassis Mount Bush Kit	SPF0206K	1	SuperPro SPF
Front	Radius Arm To Chassis Setback Bush Kit	SPF2717K	1	SuperPro SPF
Front	Radius Arm To Chassis Setback Bush Kit	SPF2718K	1	SuperPro SPF
Front	Radius Arm To Diff Mount Bush Kit - Caster Correction	SPF2509K	1	SuperPro SPF
Front	Shock Absorber Upper & Lower Bush Kit	SPF0075K	1	SuperPro SPF
Front	Shock Absorber Upper & Lower Bush Kit	SPF1879K	1	SuperPro SPF
Front	Sway Bar Link Bush Kit	SPF0078K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit	SPF0666-25K	1	SuperPro SPF
Front and Rear	Body Mount Bush Kit	SPF1788K	1	SuperPro SPF
Front and Rear	Radius Arms & Panhard Rods Bush Kit	KIT043AK	1	Vehicle Kits
Rear	Radius Arm To Diff Mount Bush Kit	SPF0129K	1	SuperPro SPF

SuperPro Suspension Parts & Poly Bushing Catalogue

More available at www.superpro.com.au



LAND ROVER RANGE ROVER Classic - 1987-1992

Position	Part Name	Part No.	Qty/Car	Sub Brand
Rear	Radius Arm To Chassis Mount Bush Kit	SPF0323K	1	SuperPro SPF
Rear	Shock Absorber Lower Bush Kit	SPF0075K	1	SuperPro SPF
Rear	Shock Absorber Upper Bush Kit	SPF0078K	1	SuperPro SPF
Rear	Shock Absorber Upper Bush Kit	SPF0779K	1	SuperPro SPF
Rear	Sway Bar Link Bush Kit	SPF0078K	1	SuperPro SPF
Rear	Sway Bar Mount Bush Kit	SPF0666-19K	1	SuperPro SPF
Rear	Trailing Arm Upper Bush Kit	SPF0128K	1	SuperPro SPF

LAND ROVER RANGE ROVER LM, L322 - 2002-2012

Position	Part Name	Part No.	Qty/Car	Sub Brand
Front	Control Arm Lower Bush Kit	SPF4494K	1	Roll Control
Front	Strut Bar To Chassis Mount Bush Kit	SPF2246K	1	SuperPro SPF
Front	Sway Bar Link Kit - Heavy Duty Adjustable	TRC12265	1	Roll Control
Front	Sway Bar Mount Bush Kit	SPF2569-30.8K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit	SPF4430K	1	SuperPro SPF
Rear	Control Arm Lower-Front Bush Kit	SPF4495K	1	Roll Control
Rear	Control Arm Upper-Front & Rear Bush Kit	SPF4497K	1	Roll Control
Rear	Differential Mount Bush Kit	SPF4502K	1	Roll Control
Rear	Sway Bar Link Kit - Heavy Duty Adjustable	TRC1245	1	Roll Control
Rear	Sway Bar Mount Bush Kit	SPF4431K	1	SuperPro SPF
Rear	Toe Arm Bush Kit	SPF1922-90K	1	SuperPro SPF

LAND ROVER RANGE ROVER LP, P38A - 1994-2002

Position	Part Name	Part No.	Qty/Car	Sub Brand
Front	Panhard Rod Bush Kit	SPF1803K	1	SuperPro SPF
Front	Radius Arm To Diff Mount Bush Kit	SPF1809K	1	SuperPro SPF
Front	Radius Arm To Chassis Mount Bush Kit	SPF0206K	1	SuperPro SPF
Front	Radius Arm To Chassis Setback Bush Kit	SPF2717K	1	SuperPro SPF
Front	Radius Arm To Chassis Setback Bush Kit	SPF2718K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit	SPF1802-31K	1	SuperPro SPF
Front and Rear	Radius Arms & Panhard Rods Bush Kit	KIT090K	1	Vehicle Kits
Front and Rear	Shock Absorber Lower Bush Kit	SPF0740K	1	SuperPro SPF
Rear	Panhard Rod Bush Kit	SPF1803K	1	SuperPro SPF
Rear	Radius Arm To Chassis Mount Bush Kit	SPF1805K	1	SuperPro SPF

LAND ROVER RANGE ROVER EVOQUE LV - 2011-on

Position	Part Name	Part No.	Qty/Car	Sub Brand
Front	Sway Bar Link Kit - Heavy Duty Adjustable	TRC10245	1	Roll Control
Rear	Sway Bar Link Kit - Heavy Duty Adjustable	TRC10160	1	Roll Control

LAND ROVER RANGE ROVER SPORT LS, L320 - 2005-on

Position	Part Name	Part No.	Qty/Car	Sub Brand
Front	Control Arm Lower-Inner Front Bush Kit	SPF3459K	1	SuperPro SPF
Front	Control Arm Lower-Inner Rear Bush Kit	SPF3456K	1	SuperPro SPF
Front	Control Arm Upper-Inner Bush Kit	SPF3486K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit	SPF3701-28K	1	SuperPro SPF
Front	Sway Bar Mount Bush Kit	SPF3701-31K	1	Roll Control
Front	Sway Bar Mount Bush Kit	SPF3701-34K	1	SuperPro SPF
Rear	Control Arm Lower-Front Bush Kit	SPF3627K	1	SuperPro SPF
Rear	Control Arm Lower-Rear Bush Kit	SPF3628K	1	SuperPro SPF
Rear	Control Arm Upper-Front Bush Kit	SPF3630K	1	SuperPro SPF
Rear	Sway Bar Link Kit - Heavy Duty Adjustable	TRC1245	1	Roll Control
Rear	Sway Bar Mount Bush Kit	SPF3631-22K	1	SuperPro SPF
Rear	Sway Bar Mount Bush Kit	SPF3631-23K	1	Roll Control
Rear	Sway Bar Mount Bush Kit	SPF3631-34K	1	SuperPro SPF

LAND ROVER Series 2, 2A, 3 88/109 - 1958-1985

Position	Part Name	Part No.	Qty/Car	Sub Brand
Front	Shock Absorber Bush Kit	SPF0078K	1	SuperPro SPF
Front	Spring Front Eye Bush Kit	SPF2154K	1	SuperPro SPF
Front	Spring Rear Eye Bush Kit	SPF2154K	1	SuperPro SPF
Front	Spring Shackle Upper Bush Kit	SPF0212K	1	SuperPro SPF
Front	Spring Shackle Upper Bush Kit	SPF2155K	1	SuperPro SPF
Front and Rear	Leaf Spring Bush Kit	KIT041K	1	Vehicle Kits
Rear	Leaf Spring Bush Kit	SPF2154K	3	SuperPro SPF
Rear	Shock Absorber Lower Bush Kit	SPF0075K	1	SuperPro SPF
Rear	Shock Absorber Lower Bush Kit	SPF1879K	1	SuperPro SPF
Rear	Shock Absorber Upper & Lower Bush Kit	SPF0078K	2	SuperPro SPF
Rear	Shock Absorber Upper Bush Kit	SPF0078K	1	SuperPro SPF